

THE ATTIC DEPOT

Conroe, Texas



Solar Attic Fan

Placement Guide for Vented Attic Spaces

Official Manufacturer Installation Guidance

Installation Requirements

1. Install the fan at the highest point of the roof line whenever possible.
2. Position the solar panel facing south, southwest, or west for maximum solar exposure.
3. Install the unit in direct sunlight. Avoid shaded areas caused by trees, chimneys, or roof structures.
4. When installing in conjunction with ridge venting, maintain a minimum clearance of 5 feet from the ridge vent.
5. Maintain a minimum clearance of 5 feet from any passive roof vents.
6. Use only the manufacturer provided anchors and hardware for secure installation.
7. Cut the zip tie securing the thermostat and allow the thermostat to hang freely into the attic space to ensure accurate temperature sensing.

Important Installation Notes

- Proper placement is critical to prevent short cycling or drawing air from nearby passive vents.
- Adequate intake ventilation must be present for optimal performance.
- Installation should be performed by qualified professionals.

For Professional Contractor Use Only

The Attic Depot | Manufacturer of Solar Attic Ventilation
Conroe, Texas | www.theatticdepot.com